

# How do I keyboard enter log curves for a well?


Copyright 2006 TERRASCIENCES

Since loading curve data is such an important function, access to the curve edit functions appear in many places throughout TerraStation. The most prominent of these is via the **Well Properties** button, visible wherever selection of the well is an option. The Well Properties window gives you options to load or edit the data.

Secondly, within several of the modules of TerraStation shortcuts to keyboard data loading are present. When you have one of the large windows displayed on screen (e.g. the **TVD Module** window), Click the **Edit** pulldown menu near the top centre/left of the window and select Well Properties.

## Loading Values One Depth at a Time

1. In the Petrophysics Module Click the **Echo** button on the power bar.
2. Either Click **Select Curves** button and select a curve/s. Or Click **Create Curve** button and create a new one.
3. Next enter a depth by Clicking on the field and typing.



M.Depth [ft]	Fred [Edit]
832.0	832.00
832.5	83
833.0	
833.5	
834.0	
834.5	
835.0	
835.5	
836.0	
836.5	
837.0	
837.5	
838.0	
838.5	
839.0	
839.5	
840.0	
840.5	
841.0	
841.5	
842.0	
842.5	
843.0	
843.5	
844.0	
844.5	
845.0	
845.5	
846.0	

Enter new value.

4. Now for each dip value, type the **Top of Interval** (into the dialog box) to the desired depth.
5. Repeat this procedure until all the data has been entered.
6. When finished Click the **Close** button.

*Thanks for using TerraStation*