






## How Do I Link A Single Map Point To A Well File?




1. Open **Mapping** from the *Main Application Bar* by Clicking the **Mapping** button. Next select Surface Elevation and Click the **Accept** button.




Note: You can skip steps 2 and 3 if your well location is already present on the map.

2. Click the **Post Points** button on the *Power Bar* followed by the **Add Point** button on the *Map Posting Options* window. Move the mouse cursor onto the map screen and Click.



3. On the *Create New Well* window fill in the new well details such as name etc. Click the **Accept** button when finished. Click the **Close** button to close the *Map Posting Options* window.



4. Find the new well on the map (It will be a red cross) and Right Click on it and then Click *Link to Well*. Select the well you wish to use and Click **Accept**.

**Thank you for using TerraStation**