



## How do I enter DST data for a well?

Copyright 2006 TERRASCIENCES

Follow these steps to display the DST symbol in the *General Engineering* track of a log plot in *IMAGELog*:

### **First, add the DST information to the database:**

1. Click on **Applications** on the *Main Applications Bar* and choose **IMAGELog** from the pull down menu. Select your well.
2. Click on the **Create New Image** button.
3. Click the **Track Setup** button.
4. Select **General Eng.** from the list of *Track Types*.
5. Click the **Track Configuration** button. You will be presented with a General Eng. Track Configuration window.
6. Put a check mark in the **Drill Stem Test** check box (If unchecked). Click on **View/Edit Data** button.
7. If the **ASCII Editing** table already contains some entries, right Click on a column and select **Insert New Row** from the pull down.
8. Right Click on the new column and select **Edit** from the pull down. You will be presented with a Well History Entry window. With this window you can add information such as **Entry Name/ID**, **Top** and **Bottom** depths and **Entry Category**. Once you have all the information you require Click **Accept** to add the information to the **ASCII Editing** table. Click **Close** to close the **Well History Entry** window.

**Well History Entry**

Feature Definition

Entry Name/ID: Test

Day Month Year: 28 Sept 06

Entry Category

- CORE - Core Sample
- DST - Drill Stem Test**
- SDWL - Sidewall Core
- PERF - Perforated Int.
- RFT
- FIT - Fluid Sample
- SHOE
- FISH
- CMP - Cement Plug
- BRGP - Bridge Plug
- TLIN - Top of Liner
- SPKR - Single Packer
- MPKR - Multiple Packer

Color: foreground

Feature Position

Position: Default

Top Depth: 1000

Bottom Depth: 1100

Feature Data and Comments

Initial Flow Time: 0

Temperature: 0 Width: 0

Accept Close

**Displaying the DST information:**

1. If it does not show automatically on screen then simply press **F2** on your keyboard.

**Thanks for using TerraStation**